



KARAOKE KRAZY 18283



CONTENTS

1 Karaoke Machine **A**

microphone **C**

video CDs **D**

adapter **F**

scart plug

This product requires, but does not include, a television

CONNECTION TO A NEWER TELEVISION

1. The Karaoke Machine **A** will connect simply to most televisions through the Audio/Visual inputs or scart socket. The scart plug is supplied.
2. Locate the Audio/Visual inputs on your television. If your television does not have Audio/Video inputs, try connecting the Karaoke Machine through a VCR. The Audio/Video inputs will be on the back or front of your television.
Please note: the connection must be IN, not OUT. If possible fit the scart plug.
3. Connect the yellow end of the Audio/Video cable **E** into 'video in' on the television. Connect the white end of the Audio/Video cable **E** into 'audio in left' and the red end of the Audio/Video cable **E** into 'audio in right' on the television or scart.
Please note: some televisions do not support both red and white audio cables in. Simply leave the white 'audio in left' cable disconnected, and the Karaoke Machine will still operate.
4. Connect the remaining red, yellow and white Audio/Video connectors to the back of the Karaoke Machine. You have now successfully connected the Karaoke Machine to your television.

CONNECTION THROUGH A VCR

1. Locate the Audio/Video inputs or scart on the back or front of your VCR.
Please note: the connection must be IN, not OUT.

2. Connect the yellow end of the Audio/Video cable **E** into 'video in' on the VCR. Connect the white end of the Audio/Visual cable **E** into 'audio in left' and the red end of the Audio/Video cable **E** into 'audio in right' on the VCR.
Please note: some VCRs do not support both red and white audio cables in. Simply leave the white 'audio in left' cable disconnected, and the Karaoke Machine will still operate.
3. Connect the remaining red, yellow and white Audio/Video connectors to the back of the Karaoke Machine. You have now successfully connected the Karaoke Machine to your VCR.

OPERATION

1. After connecting the Karaoke Machine **A** to your television/VCR, plug the AC adapter into a nearby wall outlet.
2. Plug the other end of the AC adapter **F** into the back of the Karaoke Machine.
3. Connect the microphone(s) into one of the four controller ports **B** on the front of the Karaoke Machine.
4. Switch the Karaoke Machine on by pressing the power switch on the right hand side of the machine.
5. The front LED indicator will blink red, indicating power to the machine.
6. Turn on the television/VCR and switch from TV to VIDEO*.
7. If your television has multiple video channels, tune your television until the TAO Music logo appears on your screen.
8. Press the OPEN button **G** on the front of the Karaoke Machine and the CD tray will pop out.
9. Place one of the included video CDs **D** into the tray and press OPEN again.
10. Press the PLAY button on the microphone **C** to start the video CD.
11. Make sure you turn on the power switch on the back of the microphone and turn up the microphone volume on the left hand side of the Karaoke Machine.

* Since each television/VCR set up is different and unique, please refer to your television or VCR users manual.

Switching from TV to VIDEO on a television:

One of the following options may apply to your set up:

Press TV/VIDEO on the front of the television

Press TV/VIDEO or INPUT button on the remote control

Press SOURCE on the remote control, choose INPUT, select VIDEO

Press DISPLAY on the remote control, choose INPUT, select VIDEO

Press AV on the remote control

Switching from TV to VIDEO on a VCR:

One of the following options may apply to your set up:

Press AUX, LINE or VIDEO channel below channel 2 on the VCR

Press INPUT button on the remote control

Press MENU on the remote control, choose SOURCE, switch to AUX or LINE.

SAFETY

Always supervise the use of this product.

TROUBLESHOOTING

If you have problems connecting the Karaoke Machine to your television or VCR
.... Refer to your television/VCR manual

If you can't hear yourself when the CD is playing

.... Make sure that your Karaoke Machine microphone is switched on using the ON/OFF switch on the back of the microphone. Adjust the microphone volume found on the left-hand side of the Karaoke Machine. By turning the knob towards yourself you will increase the microphone volume.

If you get a lot of feedback

.... Your Karaoke Machine microphone has specially designed to amplify your voice and all other surroundings. You may be standing too close to your television's speakers or to another home

appliance that makes noise. If your television is connected to speakers, try turning the volume on your television down and the volume on your speakers up

If your voice echoes a lot when you sing into the Karaoke Machine microphone
 The echo function on the Karaoke Machine is designed so that amateur singers would sing better. Try reducing the echo setting and ensure that the microphone is not too close to your mouth – 1 to 1.5” away is ideal.

CD Contents

Typically a set may include:

Beatles favourites:

- | | |
|---------------------|---|
| 1. Hey Jude | 8. Can't Buy Me Love |
| 2. And I Love Her | 9. Help |
| 3. Back in the USSR | 10. You're Going to Lose That Girl |
| 4. Get Back | 11. We Can Work It Out |
| 5. Come Together | 12. She Loves You |
| 6. Revolution | 13. Yellow Submarine |
| 7. Nowhere Man | 14. Sgt. Pepper's Lonely Hearts Club Band |

Club Volume 1

- | | |
|----------------------------|-----------------|
| 1. Loaded | 4. Smooth |
| 2. Shape of my Heart | 5. Come on Over |
| 3. Love Don't Cost a Thing | 6. Music |

Club Volume 2

- | | |
|---------------------------|------------------------|
| 1. Who Let the Dogs Out | 4. All Star |
| 2. As Long As You Love Me | 5. Stronger |
| 3. Independent Women Pt 1 | 6. Waiting for Tonight |

Children's Favourites

- | | |
|---------------------------------|---------------------------------------|
| 1. Mary Had a Little Lamb | 11. Michael, Row the Boat Ashore |
| 2. Old MacDonald | 12. Red River Valley |
| 3. Erie Canal | 13. My Bonnie Lies Over the Ocean |
| 4. The Happy Wanderer | 14. In and Out the Dusky Blue Bells |
| 5. Silent Night | 15. Swing Low, Sweet Chariot |
| 6. The Mulberry Bush | 16. This Old Man |
| 7. Over In The Meadow | 17. Jack & Jill |
| 8. Are You Sleeping? | 18. I've Been Working on The Railroad |
| 9. Lazy Mary (Will You Get Up?) | 19. My Old Kentucky Home |
| 10. The Gingerbread Man | |

Elvis Favourites

- | | |
|--------------------------------|-----------------------|
| 1. Return to Sender | 14. It's Now or Never |
| 2. Jailhouse Rock | |
| 3. Burning Love | |
| 4. His Latest Flame | |
| 5. Wooden Heart | |
| 6. Don't Be Cruel | |
| 7. Don't | |
| 8. Hound Dog | |
| 9. In The Ghetto | |
| 10. Can't Help Falling In Love | |
| 11. Surrender | |
| 12. Suspicious Minds | |
| 13. The Wonder of You | |

ROMPA®

KARAOKE KRAZY 18283



CONTEÚDO

1 Máquina de karaoke **A**

Microfone **C**

Video CDs **D**

Adaptador **F**

Cabo scart

Este produto necessita de uma televisão (não incluída)

LIGAÇÃO A UMA TELEVISÃO RECENTE

1. A máquina de karaoke **A** liga-se facilmente na maioria das televisões através das ligações audiovisuais ou scart. O cabo scart é fornecido.
2. Localize a ligação áudio/video da sua televisão. Se a sua televisão não tiver entrada áudio/video, tente ligar a máquina de karaoke através do vídeo. As entradas áudio/video devem estar parte de trás ou na parte da frente da televisão.
Nota: A ligação deve ser IN e não OUT. Se for possível, ligue o cabo scart.
3. Ligue a ponta amarela do cabo **E** na ligação "Video In" da televisão. Ligue a ponta branca do cabo **E** na ligação "Audio In Left" e a ponta vermelha do cabo **E** na ligação "Audio In Right" na televisão ou scart.
Nota: Algumas televisões não suportam o cabo vermelho e branco ao mesmo tempo. Nesse caso, simplesmente deixe o cabo branco desligado, a máquina de karaoke vai funcionar na mesma.
4. Ligue as outras pontas do cabo nas respetivas ligações na parte de trás da máquina de karaoke. Agora ligou com sucesso a máquina de karaoke na sua televisão.

LIGACÃO ATRAVÉS DO VIDEO

1. Localize as entradas áudio/vídeo ou scart na parte de trás ou na parte da frente do seu vídeo.
Nota: devem ser as ligações IN e não OUT.
2. Ligue o cabo amarelo na ligação “vídeo in” do seu vídeo. Ligue o cabo branco na ligação “áudio in left” e o cabo vermelho na ligação “áudio in right” do seu vídeo.
Nota: Alguns vídeos não suportam o cabo vermelho e branco ao mesmo tempo. Nesse caso, simplesmente deixe o cabo branco desligado. A máquina de karaoke vai funcionar na mesma.
3. Ligue as restantes pontas do cabo nas respetivas ligações na parte de trás da máquina de karaoke. Agora ligou com sucesso a máquina de karaoke ao seu vídeo.

FUNCIONAMENTO

1. Depois de ligar a máquina de karaoke **A** na sua televisão/vídeo, ligue o adaptador AC numa tomada.
2. Ligue a outra ponta do adaptador AC **F** na parte de trás da máquina de karaoke.
3. Ligue o(s) microfone(s) numa das quatro portas **B** na parte da frente da máquina de karaoke.
4. Ligue a máquina de karaoke pressionando o botão de ligar no lado direito da máquina.
5. O LED indicador na parte da frente vai piscar em vermelho, indicando que a máquina tem corrente.
6. Ligue a televisão/vídeo e coloque a televisão no canal de vídeo*.
7. Se a sua televisão tiver vários canais de vídeo, mude de canal até ver o logo TAO Music no ecrã.
8. Pressione o botão OPEN **G** na parte da frente da máquina de karaoke e a bandeja do CD irá abrir.
9. Coloque um dos vídeo CDs **D** incluídos na bandeja e pressione o botão OPEN novamente.
10. Pressione o botão PLAY no microfone **C** para iniciar o vídeo CD.
11. Verifique se ligou o botão na parte de trás do microfone e aumentou o volume do microfone no lado esquerdo da máquina de karaoke.

*Uma vez que cada televisão/vídeo tem uma configuração única e diferente, por favor consulte o manual da sua televisão/vídeo.

Uma das seguintes opções pode aplicar-se à sua configuração:

Pressione o botão TV/VIDEO na parte da frente da televisão

Pressione o botão TV/VIDEO ou INPUT no controlo remoto

Pressione o botão SOURCE no controlo remoto, escolha INPUT, selecione VIDEO

Pressione o botão DISPLAY no controlo remoto, escolha INPUT, selecione VIDEO

Pressione o botão AV no controlo remoto

Mudar de TV para VIDEO no vídeo:

Uma das seguintes opções pode aplicar-se à sua configuração:

Pressione o botão AUX, LINE ou VIDEO abaixo do canal 2 no vídeo

Pressione o botão INPUT no controlo remoto

Pressione o botão MENU no controlo remoto, escolha SOURCE, mude para AUX ou LINE.

SEGURANÇA

Supervisione sempre a utilização deste produto.

RESOLUÇÃO DE PROBLEMAS

Se tiver problemas a ligar a máquina de karaoke à sua televisão ou vídeo....

.... Consulte o manual da sua televisão/vídeo.

Se não se conseguir ouvir quando o CD está a tocar....

.... Verifique se o seu microfone está ligado usando o botão ON/OFF na parte de trás do microfone. Ajuste o volume do microfone que está no lado esquerdo da máquina de karaoke. Rode o botão na sua direção para aumentar o volume.

Se tiver muito feedback....

.... A sua máquina de karaoke foi especialmente concebida para amplificar a sua voz e todos os restantes sons. Pode estar muito perto da sua televisão ou de outro aparelho doméstico que faça barulho. Se a sua televisão estiver ligada a altifalantes, tente diminuir o volume da sua televisão e aumentar o volume dos altifalantes.

Se a sua voz ecoar muito quando canta na máquina de karaoke....

.... A função de eco na máquina de karaoke destina-se a ajudar os cantores amadores a cantar melhor. Tente reduzir as configurações de eco e não coloque o microfone muito perto da sua boca – o ideal é à volta de 3cm.

Conteúdos do CD

Tipicamente o conjunto inclui:

Beatles:

- | | |
|---------------------|---|
| 1. Hey Jude | 8. Can't Buy Me Love |
| 2. And I Love Her | 9. Help |
| 3. Back in the USSR | 10. You're Going to Lose That Girl |
| 4. Get Back | 11. We can Work It Out |
| 5. Come Together | 12. She Loves You |
| 6. Revolution | 13. Yellow Submarine |
| 7. Nowhere Man | 14. Sgt. Pepper's Lonely Hearts Club Band |

Club Volume 1

- | | |
|----------------------------|-----------------|
| 1. Loaded | 4. Smooth |
| 2. Shape My Heart | 5. Come on Over |
| 3. Love Don't Cost a Thing | 6. Music |

Club Volume 2

1. Who Let the Dogs Out
2. As Long As You Love Me
3. Independent Women Pt 1
4. All Star
5. Stronger
6. Waiting for Tonight

Crianças

1. Mary Had a Little Lamb
2. Old MacDonald
3. Erie Canal
4. The Happy Wanderer
5. Silent Night
6. The Mulberry Bush
7. Over In The Meadow
8. Are You Sleeping?
9. Lazy Mary (Will You Get Up?)
10. The Gingerbread Man

11. Michael, Row the Boat Ashore
12. Red River Valley
13. My Bonnie Lies Over the Ocean
14. In and Out the Dusky Blue Bells
15. Swing Low, Sweet Chariot
16. This Old Man
17. Jack & Jill
18. I've Been Working on The Railroad
19. My Old Kentucky Home

Elvis

1. Return to Sender
2. Jailhouse Rock
3. Burning Love
4. His Latest Flame
5. Wooden Heart
6. Don't Be Cruel
7. Don't

8. Hound Dog
9. In The Ghetto
10. Can't Help Falling In Love
11. Surrender
12. Suspicious Minds
13. The Wonder of You
14. It' Now or Never