



1. Product Name

Wi-Fi Interactive Mat Switch Set

2. Product Code

19939

3. Colour

As above

4. Brief Description

Nine tactile floor mats to wirelessly control the colours of your ROMPA® bubble tube; colours of your light source (carpets and fibre optics) or colours of your wall panel! Walk on the green mat to turn your SNOEZELEN® WiFi product green ... step onto purple to turn it purple ... and so on!

5. Contents

1 x Control Box

9 x Mat Switches:

- 1 x pink vinyl
- 1 x purple carpet
- 1 x blue non-slip mat
- 1 x green faux suede
- 1 x light green PU nylon
- 1 x yellow artificial grass
- 1 x orange artificial grass
- 1 x red carpet/net
- 1 x black felt

This product requires, but does not include a PP3 9V battery.

6. Snoezelen® Stimulations

- Sight
- Touch

7. Best Use

Use with ROMPA Wi-Fi compatible products to create a multi-sensory environment where the user has control to choose the colour lighting the space.

8. Compatible ROMPA® Products

ROMPA have an ever expanding range of W-Fi products including:

Ball Bubble Tubes 19767, 19768, 19769, 19770

Aquatic Bubble Tubes 19777, 19778, 19779, 19780

Fibre Optics (requires light source 19210) 17903, 19869, 17905, 17907, 17908, 19870, 19871

Please visit our website for the full exciting sensory product range www.rompa.com.

9. Starting Up

Decide how you would like to use the switch and lay out the number of mats required (you may choose not to use them all) so the user can reach them to select the colour and texture that they require. Position the user so that they can see the compatible ROMPA® Wi Fi lighting product that you have chosen to use this with (or of course multiples). Allow the user to explore the mats or perhaps demonstrate by pressing the switch to change the colours.

10. Detailed Description

Nine tactile floor mats to wirelessly control the colours of your ROMPA® bubble tube; colours of your light source (carpets and fibre optics) or colours of your wall panel! Walk on the green mat to turn your SNOEZELEN® Wi Fi product green ... step onto purple to turn it purple ... and so on!

Each mat has its own texture - and colour, matching those of our 8 Colour Wirefree Controller. Black carpet turns the colour off.

Large surface area is perfect for those without the finer motor skills to operate smaller switches and allows several users to play together and take turns. Mats can be placed on the floor or wall-mounted.

11. Safety

- Always supervise the use of this product.
- For indoor use in dry environments only.
- Only connect to an earthed mains outlet of 230Vac/50Hz.
- Installation should be carried out by a competent adult. Seek professional advice from a suitably qualified person if in doubt.
- Cease use if product becomes damaged.
- It is your responsibility to install this product safely. Use appropriate fixings.
- Never plug or unplug with wet hands.
- Do not open the product.
- Any repair should be carried out by a suitably qualified person.
- Unplug after use by pulling the plug out, not pulling on the cable.
- Do not allow the wires from the carpet switches to the control box to be a hazard e.g. do not allow anyone to trip over them.

12. Technical Specification

Carpet switch size: approx 40x32cm

Carpet switch weight: approx 200g

Cable length: from each switch approximately 240cm

Control box: battery 9V PP3

Size: 17L x 13.5W x 10cmH

Please note: not compatible with Sensory Magic

The operation of this product is wireless i.e. the switches and control box are not connected to the Wi Fi products they control. However, there must be wires from the mat switches to the control box.

13. Installation

1. Connect each carpet switch to its corresponding socket on the control box. i.e. match the number of the socket to the number indicated on the small label on the wire.



2. Some or all of the carpet switches could be wall mounted if required – fixtures are not included. Do not puncture the carpet switches. Self-adhesive Velcro could be used or a similar fixing product.
3. You may wish to use all the carpet switches at once or just some of them.



OPERATION

1. Switch the ON/OFF switch to ON (I).
2. Press the carpet switch to change the colour of the Wi Fi product(s) e.g. ROMPA® Bubble Tubes, many ROMPA® Wall Panels etc.
3. The black carpet switch switches the colour off. A second press of the black carpet switch will not switch the colour back on. To get another colour, you must press one of the other carpet switches.
4. Switch OFF after use (O).

14. Care and Maintenance

1. Replace the 9V PP3 battery as required (not included - the drawer for this is above the ON/OFF switched and is accessed from the top of the control box). Pull out the drawer holding the battery and replace the used 9V PP3 battery with a new battery of the same specification. Rechargeable batteries may be used. Remove the battery from the Control Box before recharging your battery.
2. Once eventually completely exhausted, please dispose of this product appropriately.
3. Do not attempt to open the control box – there are no user-serviceable parts inside.
4. To clean the carpet switches, wipe them with a very slightly damp, clean, soft cloth. Do not use abrasive cleaning products, solvents etc. Do not immerse the carpet switches in water.

15. Troubleshooting

- Should the colour of the Wi Fi product not correspond to the carpet switch pressed, please check that the numbers on each wire correspond with the number on the socket of the control box.
- If the carpet switches do not operate the WiFi product(s) at all, replace the 9V battery in the control box. Also, make sure that the WiFi product is switched on.
- Check that the ON/OFF switch on the control box is set to ON (I).

Further copies of these instructions can be downloaded at www.rompa.com

We hope you find our instructions invaluable. If you have any suggestions for improving them further your comments will be greatly received – please contact us at producthelp@rompa.com



1. Nome do Produto

Conjunto de Tapetes Interactivos

2. Código do Produto

19939

3. Cor

veja a imagem

4. Descrição Breve

Nove tapetes táteis para controlar sem fios as cores da sua coluna de água; cor da sua fonte de luz (tapetes via látea e fibras óticas) ou cores dos painéis interativos! Caminha em cima do tapete verde para tornar os teus produtos Snoezelen Wi-Fi verdes ... caminha em cima do roxo para os tornar roxos ... etc.

5. Conteúdo

1 x Painel de Controlo com uma pilha de 9V

9 x tapetes interactivos:

- 1 x cor de rosa (vinil)
- 1 x roxo (alcatifa)
- 1 x azul (anti-deslizante)
- 1 x verde (macio e sedoso)
- 1 x verde claro (nylon PU)
- 1 x amarelo (relva artificial)
- 1 x laranja (relva artificial)
- 1 x vermelho (alcatifa/rede)
- 1 x preto (feltro)

Este produto requer, mas não inclui uma bateria.

6. Estimulação Snoezelen®

- Visão
- Toque

7. Melhor Utilização

Controlar sem fios as cores da sua coluna de água; cor da sua fonte de luz (tapetes via látea e fibras óticas) ou cores dos painéis interativos.

8. Compatibilidade com Produtos ROMPA®

ROMPA tem uma gama de produtos W-Fi, incluindo:

Coluna de Água com bolinhas Maxi Rompa 19767, 19768, 19769, 19770

Coluna de água Oceanário 19777, 19778, 19779, 19780

Fibras óticas y Fonte de Luz 19210, 17903, 19869, 17905, 17907, 17908, 19870, 19871

Visite nosso website para obter a completa gama de produtos sensoriais www.rompa.com.

9. Começar

Pode utilizar todos os tapetes ao mesmo tempo ou apenas alguns deles.

10. Descrição Detalhada

Nove tapetes táteis para controlar sem fios as cores da sua coluna de água; cor da sua fonte de luz (tapetes via látea e fibras óticas) ou cores dos painéis interativos! Caminha em cima do tapete verde para tornar os teus produtos Snoezelen Wi-Fi verdes ... caminha em cima do roxo para os tornar roxos ... etc.

Cada tapete tem a sua própria textura e cor, correspondendo às 8 cores do controlador sem fios colorido de 8 botões. O tapete preto desliga as luzes. A sua grande superfície é perfeita para quem não possui a função motora muito apurada e não conseguem operar objetos mais pequenos, permitindo que todos joguem em conjunto. Os tapetes podem ser colocados no chão ou ser montados na parede. Contacte-nos para saber a crescente lista de produtos compatíveis.

11. Segurança

- Supervisione sempre a utilização deste produto.
- Não deixe que os fios que ligam os tapetes à caixa de controlo se tornem um perigo. Ex: não permita que alguém tropece neles.
- Para utilizar no interior num ambiente seco.

12. Especificações Técnicas

Tapetes: cada um 40 x 32cm e 200g aproximadamente.

Caixa de controlo: pilha de 9V PP3

O funcionamento deste produto é feito sem fios. Ex: os tapetes e a caixa de controlo não estão ligados aos produtos WiFi. Contudo, são necessários fios desde os tapetes até à caixa de controlo.

13. Instalação

1. Ligue cada tapete na entrada correspondente na caixa de controlo. Ex: faça corresponder o número da entrada com o nº indicado na etiqueta do fio.



2. Alguns ou todos os tapetes podem ser montados na parede, se necessário – os acessórios de fixação não estão incluídos. Não fure os tapetes. Pode ser utilizado velcro ou um produto de fixação semelhante.
3. Pode utilizar todos os tapetes ao mesmo tempo ou apenas alguns deles.



FUNCIONAMENTO

1. Coloque o botão ON/OFF na posição ON (I).
2. Pressione o tapete para mudar a cor dos seus produtos WiFi. Ex: colunas de água, fonte de luz, totem de difração de luz, muitos painéis de parede Rompa, etc.
3. O tapete preto, desliga a cor. Se voltar a pressionar o tapete preto a cor não volta a ligar-se. Para obter outra cor, deve pressionar outro tapete.
4. Desligue depois de utilizar (O).

14. Cuidado e Manutenção

1. Substitua a pilha de 9V sempre que necessário (o compartimento das pilhas está situado acima do botão ON/OFF e é acessível a partir do topo da caixa de controlo). Puxe o suporte da pilha e substitua-a por uma nova com as mesmas características.
2. Quando estiver totalmente gasto, coloque este produto num local apropriado.
3. Não tente abrir a caixa de controlo – não existem peças que os utilizadores possam substituir no seu interior.
4. Para limpar os tapetes, utilize um pano ligeiramente húmido, limpo e macio. Não utilize produtos abrasivos, solventes, etc. Não submerja os tapetes em água.

15. Resolução de Problemas

- Se a cor de um produto WiFi não corresponder ao tapete pressionado, verifique se o número do fio corresponde ao número da caixa de controlo.
- Se o tapete não controlar os produtos WiFi, substitua a pilha de 9V na caixa de controlo. Verifique também se todos os produtos WiFi estão ligados.
- Verifique se o botão ON/OFF na caixa de controlo está na posição ON (I).