



## **1. Product Name**

Interactive Games Galore by ROMPA®

## **2. Product Code**

20031

## **3. Colour**

As per the image above.

## **4. Brief Description**

This funky floor has hidden surprises! Five squares have sounds or lights – will you be the one to step on them to activate these sensory rewards? Take turns or throw a dice to move over the squares in sequence.

## **5. Contents**

- 1 x Games Galore floor
- 1 x Speaker and light unit

## **6. Snoezelen® Stimulations**

- Sight
- Sound

## **7. Best Use**

Use indoors, in a suitably located area

## **8. Compatible ROMPA® Products**

ROMPA® offer a variety of wall and floor cushioning for sensory and play areas and these come in a large range of colours. We also have many interactive play or sensory items and can offer bespoke products, manufactured to your specifications.

We also have a range of practical, rehabilitation, healthcare and sensory resources for people who have a range of needs. Please look at [www.rompa.com](http://www.rompa.com) for our full range.

## **9. Starting Up**

- Plug in and switch on at the wall.
- Step on the different squares. Five are interactive and the rest are non-interactive. Two activate lights and three activate sounds.
- Make sure users have removed their shoes.
- Adjust the angle of the lights as required.

## **10. Detailed Description**

This funky floor has hidden surprises! Five squares have sounds or lights – will you be the one to step on them to activate these sensory rewards? Take turns or throw a dice to move over the squares in sequence. Move forward extra squares at the lights or move back upon hearing the sounds! Your cushion, your games! This product contains wood.

## **11. Safety**



Please read all the following safety information before each use

### **ALWAYS SUPERVISE THE USE OF THIS PRODUCT**

- Use indoors, in dry environments.
- Remove all packaging and either store this in a safe place out of reach of clients or dispose of this responsibly. Plastic bags and wrapping can be hazardous to children and vulnerable people.
- Organise a regular cleaning schedule.

- Vinyl will crack, tear and rub off if subjected to sharp objects or continual rubbing by hard objects. Remove shoes, and avoid buckles, zips or sharp/hard/pointed objects coming into contact with the surface.
- Check seams regularly to ensure that these are not worn or split and the interior filling cannot be accessed.
- Wipe off accidental marks/liquids at the time they occur or are noticed.
- From time to time, if possible, lift floor cushion or move furniture to clean all surfaces and the floor underneath.
- Furniture and cushioning is intended to provide comfort and relaxation. Avoid eating and drinking whilst using these products.
- Steam cleaning is not recommended.
- Do not place near sources of heat or fire that may damage the surface (radiators, fires, underfloor heating, hot central heating pipes etc.)
- Direct contact with bright sunlight may affect material over time.
- Do not saturate the material with lots of water.
- Some of our products contain zips for manufacturing purposes only. Do not attempt to open these or to access the interior part of these products. Never allow children or vulnerable people to access the interior part of this product.
- Do not pull on the cables

## **12. Technical Specification**

Size:	145 x 145 x 15cm
Weight:	40kg (speaker and light unit is approximately 3kg)
Input:	240V (Fuse: 3amp fuse)
Material:	Phthalate-free vinyl

## **13. Installation**

Install the Interactive Games Galore in an appropriate place on a flat, stable surface, bearing in mind the following:

- The size of the floor: 145 x 145 x 15cm
- The weight of the floor: 40kg
- Access to a wall socket – the speaker and light unit needs to be plugged in and you may wish to wall mount this out of reach
- Cushioning around the floor
- The length of the cable: floor to unit 4.5m

## **14. Care and Maintenance**

### **PVC (Vinyl)**

- Use a soft brush remove all loose dust/dirt
- Clean with a mild detergent (such as Lux soap flakes in luke-warm solution) applied to a sponge or damp cloth.
- This may be sanitised using a weak solution of Milton fluid.
- Do not use excessive amounts of water and always ensure the PVC is dry after cleaning.
- Do not use an abrasive cleaning pad.
- Do not use boiling/very hot water, washing up liquid / aggressive detergent or solvent based cleaner as this will cause the coating to discolour and go hard.
- Steam cleaning is not advised.

## **15. Troubleshooting**

*Not applicable*

Further copies of these instructions can be downloaded at [www.rompa.com](http://www.rompa.com)

We hope you find our instructions invaluable. If you have any suggestions for improving them further your comments will be greatly received – please contact us at

[producthelp@rompa.com](mailto:producthelp@rompa.com)



## **1. Nome do Produto**

Jogos Galore Interativos ROMPA®

## **2. Código do Produto**

20031

## **3. Cor**

Como a imagem

## **4. Descrição Breve**

Este estranho chão tem surpresas escondidas! Cinco quadrados têm sons ou luzes – serás tu quem vai pisá-los para ativar as recompensas sensoriais? Joga à vez ou atira um dado para mover todos os quadrados sequencialmente.

## **5. Conteúdo**

1 x Chão Jogos Galore  
1 x Altifalantes e unidade luminosa

## **6. Estimulação Snoezelen®**

- Visão
- Som

## **7. Melhor Utilização**

Para uso interno

## **8. Compatibilidade com Produtos ROMPA®**

Por favor visite [www.rompa.com](http://www.rompa.com)

## **9. Começar**

- Ligue na tomada.
- Pise em diferentes quadrados. Cinco são interativos e o resto não são interativos. Dois ativam luzes e três ativam sons.
- Os utilizadores devem remover os sapatos.
- Ajuste o ângulo das luzes conforme necessário.

## **10. Descrição Detalhada**

Este estranho chão tem surpresas escondidas! Cinco quadrados têm sons ou luzes – serás tu quem vai pisá-los para ativar as recompensas sensoriais? Joga à vez ou atira um dado para mover todos os quadrados sequencialmente. Movimenta os quadrados extra para a frente em direção à luz ou move-os para trás se ouvires sons! O teu colchão – Os teus jogos! Este artigo tem madeira.

## **11. Segurança**



Leia todas as informações de segurança antes de cada utilização

### **SUPERVISE A UTILIZAÇÃO DESTE PRODUTO**

- Utilize no interior, em ambientes secos.
- Retire a embalagem. Armazene a embalagem com segurança e fora de alcance ou jogue fora adequadamente. Os sacos plásticos e o embalagem podem ser danificadores.
- Organize uma agenda de limpeza regular.
- O vinil vai rachar, rasgar e “desgastar” se for sujeito a objetos afiados ou se for roçado continuamente por objetos duros. Evite utilizar sapatos, fivelas ou objetos afiados/duros.
- Verifique regularmente as costuras para garantir que o enchimento não é acessível.

- Limpe líquidos ou marcas acidentais imediatamente com um detergente macio e um pano húmido, evitando quantidades excessivas de água.
- Não comer ou beber ao usar este produto.
- Não lave com vapor.
- Use e guarde longe de fontes de calor, fogo e luz solar direta.
- Alguns dos nossos produtos contêm zíperes apenas para fins de fabricação. Não tente abrir estes ou para acessar a parte interior destes produtos.
- Use e guarde longe de fontes de calor, fogo e luz solar direta.
- Não utilize produtos de limpeza com abrasivos ou à base de solventes.
- Não utilize detergente líquido da loiça. Não utilize produtos que contenham lixívia.
- Não puxe os cabos.

## **12. Especificações Técnicas**

Tamanho: 145 x 145 x 15cm

Peso: 40kg (o altifalante e unidade de luz pesam aproximadamente 3kg)

Entrada: 240V (fusível: 3amp)

Vinil sem ftalato

## **13. Instalação**

Instale os Jogos Galore Interativos num local apropriado, numa superfície plana e estável, tendo em consideração o seguinte:

- O tamanho do chão é 145 x 145 x 15cm
- O peso do chão: 40kg
- Acesso a uma tomada – o altifalante e unidade de luz precisam de ser ligadas na tomada, se desejar pode montar na parede fora de alcance.
- Os colchões à volta do chão
- O comprimento do cabo: do chão até à unidade 4.5m

## **14. Cuidado e Manutenção**

### **Vinil**

- Use uma escova macia para remover toda a poeira / sujeira soltas.
  - Limpe líquidos ou marcas acidentais imediatamente com um detergente macio e um pano húmido. Não utilize uma esponja abrasiva.
  - Podem ser utilizados líquidos esterilizantes para mamadeiras.
  - Limpe com um pano húmido, evitando quantidades excessivas de água.
  - Não use água fervente / muito quente.
  - Não lave com vapor.
- 
- Este produto utiliza LEDs, portanto não é necessário substituir nenhuma lâmpada.

## **15. Resolução de Problemas**

*Não aplicável*