



1. Product Name

Bubbles

2. Product Code

23010

3. Colour

May vary

4. Brief Description

A machine that blows bubbles at the press of your switch (not included)

5. Contents

- Bubbles machine with cable attached (cable has a battery compartment on it)
 - 1 x small plastic container of bubble fluid 118ml
- Please note: Bubbles requires, but does not include 2 x AA batteries and a switch



6. Snoezelen® Stimulations

- Sight

7. Best Use

Use indoors, connected to a switch.

8. Compatible ROMPA® Products

This switch adapted bubble machine can be used with many different switches. See www.rompa.com to view our full range.

9. Starting Up

- Place batteries into compartment (see instructions below).
- Add bubble liquid.
- Connect a switch to the bubble machine by plugging it into the socket on the end of the cable.
- Activate the bubble machine by activating the switch you have just connected. The machine is activated whilst your switch is activated (held down etc.).
- Remember to switch the bubble machine and the battery compartment OFF after use.

10. Detailed Description

The stuff of dreams! A machine that blows glorious bubbles at the press of your switch. Rewarding and appealing. Includes bubble mixture.

11. Safety

Always supervise the use of this product.

- Use indoors in a dry environment.
- Take care with the cable – make sure it cannot be a trip hazard etc.
- Do not allow the bubble liquid to be swallowed.

12. Technical Specification

Size: 14cmH

Jack socket: 3.175mm

13. Installation

1. Open the battery compartment (small black rectangular box on the cable). To open, remove the small positive screw that holds down the lid. Keep the screw in a safe place!



2. Insert 2 AA batteries observing the polarity indicated.



3. Replace the battery compartment lid and screw.
4. Slide the small switch on the battery compartment to ON.



5. With the battery compartment being positioned on the cable, there is no need to open the bubble machine itself. It is not necessary to attempt to install batteries into the back of the bubble machine.



6. Pour some bubble liquid into the trough at the front– do not over-fill.
7. Connect the bubble machine to a switch (not included) via the jack socket at the end of the cable (as shown).



8. Switch the bubble machine ON.
9. Activate your switch.

14. Care and Maintenance

- Do not immerse the unit in water.
- Surface wipeable only.
- Use a soft, clean cloth and a minimal amount of a cold, mild soap solution.
- Do not use bleach or an abrasive cleaning product. Allow to air dry naturally.
- Replace the batteries as required.
- Empty out all the bubble liquid after use and before storing away.
- Remove the batteries when the bubble machine is not in use for prolonged periods.
- Do not use rechargeable batteries, and do not mix old and new batteries.
- Do not pull on the cable.

15. Troubleshooting

Not applicable.

Further copies of these instructions can be downloaded at www.rompa.com

We hope you find our instructions invaluable. If you have any suggestions for improving them further your comments will be greatly received – please contact us at producthelp@rompa.com



1. Nome do Produto

Bolhas!

2. Código do Produto

23010

3. Cor

Cores podem variar

4. Descrição Breve

Material de sonhos! Uma máquina que lança gloriosas bolhas com um toque no teu switch.

5. Conteúdo

- 1 x Máquina de bolhas com um cabo
(o cabo possui um compartimento de pilhas)
- 1 x Pequeno recipiente com líquido de bolhas 118ml

Nota: Este produto necessita de 2 pilhas AA e de um switch, não incluídos.



6. Estimulação Snoezelen®

- Visão

7. Melhor Utilização

Active a máquina de bolhas com um switch.

8. Compatibilidade com Produtos ROMPA®

Veja www.rompa.com para a nossa gama completa de switches.

9. Começar

- Abra o compartimento das pilhas e introduza 2 pilhas.
- Ligue a máquina de bolhas a um switch.
- Coloque algum líquido no recipiente cor de laranja
- Active a máquina de bolhas com o switch
- Lembre-se de desligar a máquina de bolhas e o compartimento das pilhas depois de utilizar

10. Descrição Detalhada

Material de sonhos! Uma máquina que lança gloriosas bolhas com um toque no teu switch. Recompensador, maravilhoso e apelativo. Inclui a mistura das bolhas. Necessita de 2 pilhas AA e de um switch.

11. Segurança

Supervisione sempre a utilização deste produto

- Usar dentro de casa em um ambiente seco.
- Não puxe pelo cabo.
- Não ingerir o líquido.

12. Especificações Técnicas

Tamanho: 14cm

Jack: 3.175mm

13. Instalação

1. Abra o compartimento das pilhas (pequena caixa rectangular preta no cabo). Para abrir, remova o pequeno parafuso que a prende. Guarde o parafuso!



2. Introduza 2 pilhas AA tendo em atenção a polaridade indicada.



3. Volte a colocar a tampa do compartimento das pilhas e parafuso.
4. Coloque o pequeno botão no compartimento das pilhas na posição ON.



- Com o compartimento das pilhas situado no cabo, não há necessidade de abrir a máquina de bolhas. Não é necessário tentar instalar pilhas na parte de baixo da máquina de bolhas.



- Coloque algum líquido no recipiente – não encha demasiado.
- Ligue a máquina de bolhas a um switch (não incluído) através do Jack na ponta do cabo (conforme ilustrado).



- Ligue a máquina de bolhas.
- Active a máquina de bolhas com o switch que deve ter ligado. A máquina fica activada enquanto o switch estiver activado (enquanto pressionado, etc.)
- Lembre-se de desligar a máquina de bolhas e o compartimento das pilhas depois de utilizar.

14. Cuidado e Manutenção

1. Não submerja a unidade em água. Apenas a superfície pode ser limpa. Utilize um pano limpo e uma quantidade mínima de detergente macio. Não utilize lixívia ou um produto de limpeza abrasivo. Deixe secar ao natural.
2. Substitua as pilhas quando necessário.
3. Esvazie o compartimento com líquido antes de guardar.
4. Remova as pilhas quando não utilizar este produto por longos períodos.
5. Não utilize pilhas recarregáveis e não misture pilhas novas com pilhas velhas.
6. Não puxe pelo cabo.

15. Resolução de Problemas

não aplicável