Copyright ROMPA® Ltd

SOFT TOUCH LOLLIPOP SWITCH 19293-8, 19202

DESCRIPTION
Touch the soft lightly textured surface to engage the switch and operate any adapted item. The switch has a non-slip base.

CONTENTS
1 x Lollipop Switch
1 x Cable and adapter (attached to the switch)

OPERATION
1. Connect the switch to a switchable item using the cable provided.
2. Activate the other item by applying pressure to the switch. A click indicates that the switch has been activated.

CARE AND MAINTENANCE
Wipe the unit clean using a mild household multi-purpose cleaner or disinfectant. Do not use abrasive cleaners as these will scratch the surface of the unit. Do not immerse the unit in water.

TECHNICAL INFORMATION
This is a simple switch, and a mono switch. Always check whether items are mono or stereo. ROMPA cannot be held responsible for damage caused to items that are not suitable for use with this switch.

Copyright ROMPA® Ltd

SWITCH LOLLIPOP TOQUE SUAVE 19293-8, 19202

DESCRIÇÃO
Toque a superfície de textura macia para activar o switch e operar qualquer item adaptado. O switch possui uma base anti deslizante.

CONTEÚDO
1 x Switch lollipop
1 x Cabo e adaptador (fixados no swich)

FUNCIONAMENTO
1. Ligue o switch ao objecto activado por switch, utilizando o cabo fornecido.
2. Active o outro objecto aplicando pressão no switch. Um clique indica que o switch foi activado.

CUIDADO E MANUTENÇÃO
Limpe com um detergente macio multiusos ou com um desinfectante. Não utilize produtos abrasivos pois estes danificam a superfície do produto. Não submerja em água.

ESPECIFICAÇÕES TÉCNICAS
Este é um switch simples e um switch mono. Verifique sempre se os objectos são stereo ou mono. A Rompa não se pode responsabilizar por danos causados em produtos que não sejam adequados para utilizar com este switch.