

## ASSEMBLY INSTRUCTIONS

(Fixing Kit:- 8 x 100mm screws).

**PLEASE NOTE THAT ASSEMBLY WILL REQUIRE AT LEAST TWO ADULTS.**

1. Place in selected area on flat level ground.
2. Place both side panels in position, making sure they are plumb level, and lay roof section across top.
3. Make sure all 4 posts are sat flush in corners of roof, and fix into marked pre-drilled holes, using 8 x 100mm screws. 2 each side, 1 through front and 1 through side. (As shown in images below).



Image of completed product.



