



BALANCE SAUCER 15861



CONTENTS

Your Balance Saucer is supplied in one box containing:



1 x saucer
1 x cover (both shown to left)



1 x bag of hardware (handles, washers and screws)




1 x block of foam

NOTE: Upon opening the packaging, do not discard the foam and bag of hardware

ASSEMBLY

1. Place the foam block in the centre of the saucer as shown.
2. Place the cover on top.
3. Securely attach the handles using the screws, washers and the pre-drilled holes in the rim of the saucer and cover.

**USE**

Use on a flat, stable surface.

Use away from steps, stairs, slopes etc.

Do not exceed maximum weight supported: 60kg.

For indoor and outdoor use.

Stand or sit on the saucer according to client's ability and needs.

Use appropriately for supervised balance activities.

SAFETY

Always supervise the use of this product.

Periodically check that the handles are securely attached.

STORAGE

Store in a safe, dry place that is out of reach of clients.

CLEANING

Plastic – clean with a slightly damp cloth and mild cleaning product. Avoid abrasive cleaning products as this will scratch the Balance Saucer.

SPECIFICATION


Size: 76cm diameter x 14.5cmH

Plastic

Maximum weight supported: 60kg



DISCO DE BALANÇO 15861



CONTEÚDO

O seu disco de balanço é fornecido numa caixa que contém:



1 x Disco
1 x Cobertura (ambos ilustrados à esquerda)



1 x Saco de ferragens (pegas, anilhas e parafusos)

1 x bloco de espuma



NOTA: Depois de abrir a embalagem, não deite fora a espuma e saco de ferragens

MONTAGEM

1. Coloque o bloco de espuma no centro do disco conforme ilustrado.
2. Coloque a cobertura no topo.
3. Fixe bem as pegas utilizando os parafusos, anilhas e os furos pré feitos no aro do desco e cobertura.



UTILIZAÇÃO

Utilize numa superfície plana e estável.

Utilize longe de degraus, escadas, declives, etc.

Não exceda o peso máximo suportado: 60kg.

Para utilizar no interior e no exterior.

Pode ser utilizado de pé ou sentado, dependendo das capacidades e necessidades do cliente.

Utilize de forma apropriada em atividades de equilíbrio supervisionadas.

SEGURANÇA

Supervisione sempre a utilização deste produto.

Verifique periodicamente se as pegas estão bem fixas.

ARMAZENAMENTO

Guarde num local seguro e seco, fora do alcance dos clientes.

LIMPEZA

Plástico – Limpe com um pano ligeiramente húmido e com um produto de limpeza suave. Evite produtos de limpeza abrasivos para não riscar o disco de balanço

ESPECIFICAÇÕES

Tamanho: 76cm de diâmetro x 14.5cmA

Plástico

Peso máximo suportado: 60kg