



## **1. Product Name**

Slot Together Ballpool

## **2. Product Code**

18486

## **3. Colour**

Multi-coloured

## **4. Brief Description**

Colourful play area, idea for use as a ballpool. Slot together construction for several shape and size options.

## **5. Contents**

32 pieces – 16 of two types

Balls are not included – see below for an approximate guide to the amount of balls required

## **6. Snoezelen® Stimulations**

- Sight
- Touch
- Proprioception/Vestibular

## **7. Best Use**

Use as a soft play area or fill with balls to create a ballpool. Vary construction to change the shape and size, creating different areas for therapy and play purposes.

## **8. Compatible ROMPA® Products**

13674 - 7cm diameter balls mixed colours

14346 - Clear balls

18280 - Auto ballpool ball washer

15283 – Net Washing Bag

## **9. Starting Up**

Slot together and fill with balls (if appropriate).

## **10. Detailed Description**

Colourful play area ideal for use as a ballpool. Cleverly-designed slot-together construction for several shape and size combinations. Balls to be purchased separately - depending on the combination/height created, approximately 2-25 boxes of balls required. See installation instructions below for more information. Use just one layer of blocks for a 30cm high pool or two layers for a 52cm high pool.

## **11. Safety**

- Always supervise the use of this product.
- Position in a suitably safe location.
- Protective safety matting surrounding the ballpool is advisable.

## **12. Technical Specification**

Weight: Each piece 2.1kg


Size: each 12.5cm at the widest point x 30/52cmH.

### 13. Installation

Decide on the shape/height of the equipment. Several variations are possible:

#### Wavy


Requires all 32 pieces. This is 52cm high and requires approximately 13 boxes of 7.5cm balls (or 25 boxes of 6cm balls – no longer available from ROMPA®).



#### Low circle

This is 30cm high, and requires 8 pieces.

It requires approximately 2 boxes of 7.5cm balls (or 3 boxes of 6cm balls – no longer available from ROMPA®):




#### High circle

As above, but using two layers and 16 pieces.

This is 52cm high and requires approximately 4 boxes of 7.5cm balls (or 8 boxes of 6cm balls – no longer available from ROMPA®).

Slot the pieces together. The pieces that are rounded at the top are uppermost.



Please note: the pieces are quite stiffly linked and quite difficult to separate once linked. This is a safety feature to ensure that the pieces are not easily and unintentionally separated during use. You may wish to lay the pieces out without slotting them together to work out the shape of the play area or ballpool you require.

Note the approximate size of the ballpools detailed above and consider the intended use and space you have available when choosing the shape.

Please note: the quantities of balls required are approximate. These quantities allow for the balls to fill the ballpool with a 15cm allowance to the top – otherwise the balls would spill over as users get inside. You may wish to use more or less balls.

## 14. Care and Maintenance

- Wipe clean after use with a soft cloth dampened with a diluted, non-abrasive disinfectant or cleaning product.
- Surfaces must be dried before use.
- Remove shoes before play.
- Store carefully.
- If balls are used, ensure these are also kept clean. It is possible to purchase an automatic ball washer for convenience (see Auto Ball Washer 18280).

## 15. Troubleshooting

*Not applicable*

Further copies of these instructions can be downloaded at [www.rompa.com](http://www.rompa.com)

We hope you find our instructions invaluable. If you have any suggestions for improving them further your comments will be greatly received – please contact us at [producthelp@rompa.com](mailto:producthelp@rompa.com)



## 1. Produit

Piscine à Balles à Monter

## 2. Code

18486

## 3. Couleur

Multi-coloré

## 4. Brève description

Espace de jeux coloré idéal à utiliser comme piscine à balles. Conçu avec des arrondis qui s'empilent pour faire différentes formes et combi.

## 5. Contenu

32 blocs – 16 de deux sortes

Les balles ne sont pas comprises – voir plus bas pour un guide approximatif à la quantité de balles nécessaire

## 6. Stimulations Snoezelen®

- Vue
- Toucher
- Proprioception/Vestibulaire

## **7. Usage**

Servez-vous de ce produit comme coin de jeux ou comme piscine à balles. On peut varier la forme et les dimensions de la piscine selon vos besoins.

## **8. Products Compatibles de ROMPA®**

13674 - balles 7cm diamètre couleurs mixtes

14346 – balles transparentes

18280 – machine pour l'entretien des piscines à balles

15283 – filet de rangement de nettoyage

## **9. Fonctionnement**

Attachez les pièces et remplissez la piscine de balles.

## **10. Description**

Espace de jeux coloré idéal à utiliser comme piscine à balles. Conçu avec des arrondis qui s'empilent pour faire différentes formes et combinaisons. Balles non livrées. Utilisez une couche de bloc pour une piscine à balles de 30 cm de hauteur ou 2 couches pour en avoir une de 52 cm de haut. Durable et facile à nettoyer. Set de 32 blocs.

## **11. Sûreté**

- Il faut toujours surveiller l'usage de ce produit.
- Positionnez la piscine dans un lieu sûr et convenable.
- Nous vous conseillons d'utiliser les matelas.

## **12. Caractéristiques Techniques**

Poids: chaque bloc 2.1kg


Dimensions: chaque bloc 12.5cm (le point le plus large) x 30/52cmH.

### 13. Installation

Décidez la forme et la hauteur de la piscine. Plusieurs variations sont possibles:

#### Ondes


Cette piscine nécessite toutes les 32 pièces. Elle mesure 52 cm de hauteur et nécessite environ 13 boîtes de balles de 7,5cm (ou 25 boîtes de balles de 6 cm).



#### Cercle Basse

Cette cercle est 30 cm de hauteur, et nécessite 8 pièces.

Elle nécessite environ 2 boîtes de balles de 7,5 cm (ou 3 boîtes de balles de 6 cm):



#### Cercle Haute

Comme l'autre cercle, mais il a deux rangs et nécessite 16 pièces.

Elle mesure 52 cm de hauteur et nécessite environ 4 boîtes de balles de 7,5 cm (ou 8 boîtes de balles de 6 cm).

Attachez les pièces. Les pièces avec le dessus arrondi se trouvent au-dessus de la piscine.

Tenez compte des dimensions des piscines et de l'espace disponible.



Prière de noter : les pièces se serrent bien. Intentionnellement il est difficile de les séparer – c'est pour la sûreté pendant l'usage. C'est une bonne idée de mettre les pièces l'un à côté de l'autre avant de les serrer pour trouver la forme de piscine voulue.

Prière de noter : les quantités de balles sont approximatives. Ces quantités se tiennent compte de 15 cm au dessus de la piscine – sinon les balles répandent dès que les usagers entrent la piscine. C'est à vous – on peut ajouter plus ou moins de balles.

## **14. Soin et Entretien**

- Essayez le produit avec un chiffon légèrement humecté et un produit de nettoyage doux et non-abrasif.
- Laissez sécher le produit avant d'usage.
- Quittez les chaussures avant de jouer.
- Entrez ce produit avec soin.
- Assurez-vous que les balles restent propres. On peut acheter une machine pour laver les balles (voir 18280 plus haut).

## **15. En cas de problèmes**

*Ne s'applique pas*