



## RIB-IT-BALL 19502



### CONTENTS

- 1 x Rib-It-Ball
- 2 x balloon inserts
- 1 x re-usable balloon tie (disk, see below right)

### BEFORE USE

1. Locate the opening along one of the ribs. This is near to the small white label. This opening is approximately 15cm long and is fastened with Velcro.



2. Insert a balloon insert in the ball so that the neck of the balloon can be held through the opening.

3. Inflate the balloon by mouth or ball pump, keeping hold of the neck and making sure the rest of the balloon stays inside the ball. Once the balloon is satisfactorily inflated and the fabric of the ball is quite taut around the balloon, attach the re-usable tie:
  - a. Gently stretch the neck of the balloon.
  - b. Slide the neck of the balloon through the long slot of the tie to the centre of the tie
  - c. Pass the end of the neck then through one of the short slots
  - d. Then pass the end of the neck back down through the long slot
4. Tuck the balloon tie into the Velcro opening and close the Velcro



## CARE & MAINTENANCE

It is recommended that this product be surface washed only.

Allow to air dry naturally.

Replace the balloons as necessary. The re-usable tie allows the balloon to be inflated and deflated as required.

## SAFETY

Always supervise the use of this product.

Keep un-inflated balloons and small parts such as the tie away from small children and those who might mouth/swallow small objects if they were not supervised. Keep all parts stored safely. Discard any damaged/broken balloons.

## SPECIFICATION

All new materials

Meets all the requirements of EN71 and ASTM



## BOLA RIB-IT-BALL 19502



### CONTEÚDO

- 1 x Bola Rib-it
- 2 x Balões insufláveis para o interior da bola
- 1 x Selo reutilizável para o balão (disco, ver abaixo à direita)

### ANTES DE UTILIZAR

1. Localize as aberturas. Estão perto de uma pequena etiqueta branca. Esta abertura tem aproximadamente 15cm e aperta-se com velcro.



2. Introduza o balão dentro da bola, de forma que o gargalo do balão possa ser agarrado através da abertura.

3. Encha o balão a sopro ou com uma bomba, segurando o gargalo e deixando o resto do balão dentro da bola. Quando o balão estiver devidamente cheio e o tecido da bola estiver bem acomodado à volta do balão, prenda o selo (disco vermelho):
  - a. Estique cuidadosamente o gargalo do balão.
  - b. Deslize o gargalo do balão através da ranhura no centro do selo.
  - c. Passe o gargalo por uma das ranhuras mais curtas.
  - d. Depois passe a ponta do gargalo pela ranhura grande.
4. Enfie o selo dentro da abertura de velcro e feche.



## CUIDADO E MANUTENÇÃO

É recomendado lavar este produto apenas superficialmente.

Deixe secar naturalmente.

Substitua os balões quando necessário. O selo reutilizável permite encher e esvaziar o balão sempre que necessário.

## SEGURANÇA

Supervisione sempre a utilização deste produto.

Mantenha os balões vazios e peças pequenas tais como o selo afastadas de crianças pequenas e utilizadores que as possam colocar na boca. Mantenha todas as peças guardadas em segurança. Deite fora qualquer balão estragado.

## ESPECIFICAÇÕES

Conforme EN71 e ASTM