



Product: Sound Responsive Traffic Light

Product Code: 55695



Contents:

- Sound Responsive Traffic Light (L x H x D) 13,8 x 44 x 11 cm
- Power-Pack-Unit
- Instructions

How to use the Sound Responsive Traffic Light:

- The Sound Responsive Traffic Light can be placed on a table or attached to a wall.
- If fixing to a wall, there are two suspension areas in the back of the unit. It can be attached using nails or screws.
- Stand (tripod) Turn down the two adjustment clips in the back of the unit and you can attach it to a stand.
- Steel board (optional): 4 magnets are provided in the back for attachment to anything metallic such as a steel board or a whiteboard.

Where to place the Sound Responsive Traffic Light:

- Find a place which is neither too hot, nor moist or wet.
- The device always reacts to the nearest noises. For example, if you place it next to an open window it will also react to the outside noises.
- Try out different places and find the most suitable placement for you and your group, preferably situated in an area close to your group.

Electricity-operated:

- Use only the power-pack included.
- First attach the Sound Responsive Traffic Light to the power-pack. Then connect the power-pack to the power supply.
- Place the power cable in a suitable and safe location, where it won't be pulled, squashed or put under any strain.

Rechargeable battery operation:

- Open the battery-chamber in the back of the Sound Responsive Traffic Light.
- Install 4 rechargeable batteries (type AAA) in the chamber.
- Recharging of the rechargeable batteries: First attach the Sound Responsive Traffic Light to the power-pack. Then connect the power-pack to the power supply.
- When the batteries are charged, remove the power-pack. The Sound Responsive Traffic Light can now be operated without the power-pack.

How to set the Sound Responsive Traffic Light properly:

- Switch the Sound Responsive Traffic Light on. It will switch to red for 3 seconds and then to green.
- Whenever you change the setting of the alarm, it will turn to red for 2 seconds and then to green.
- Select the setting siren included or siren excluded by pressing the button 'siren on/off'.
- Choose the actual volume-setting according to the situation (see below guidance).

Level Approx. Decibel:

Approx. 50 - 60 Silent work

Approx. 60 - 70 Quiet talk

Approx. 70 - 80 Normal talk

Approx. 80 - 90 Very loud talk

Approx. 90 - 100 Beginning of ear damage, when continued.

Approx. 100 - 120 Danger: Possibility of serious ear damage.

Cont/d

- The Sound Responsive Traffic Light shows green as long as the chosen volume setting is kept.
- When the level is exceeded, the yellow light starts blinking as a warning. When the level exceeds more than approximately 15 decibel, the Sound Responsive Traffic Light switches to red (according to the setting) the siren sounds.
- If you want to use the Sound Responsive Traffic Light as a traffic-light turn the volume button to the colour you want. The light will then shine constantly green, yellow, or red.

Illumination

- The Sound Responsive Traffic Light works with LED-lights.
- These lights have an average lifetime of approximately 100000 working hours.

How to find eventual faults:

- The lights do not work - Check whether the batteries are loaded, or the power-supply set up.
- The lights keep changing - you may have just started the set, or you have just set the decibel-grading. The set shows that changes have been made.
- The lights don't switch off - The control unit shows that one of the lights might be defective.
- The siren or the on/off switch doesn't work - The set might be damaged. Please contact Winslow.

Maintenance of the Sound Responsive Traffic Light

- Always switch the Sound Responsive Traffic Light off after use.
- Before you clean it, disconnect the power supply.
- Clean it only with a soft cloth. Fingerprints or patches might be wiped with a slightly moist cloth.
- Keep the Sound Responsive Traffic Light in a cool and dry place.

Warnings and conditions for use:

- Keep the instructions for reference.
- The Sound Responsive Traffic Light is only to be used during school-lessons or similar situations.
- This is not a toy.
- Do not expose it to heat, moisture or wet – (danger of short circuit).
- Use only rechargeable batteries for the charger.
- Normal batteries might run out.