

**1. Product Name**

Wall Bracket

**2. Product Code**

14817

**3. Colour**

As available

**4. Brief Description**

Suitable for use where existing ceiling is too high or not strong enough.

**5. Contents**

- 1 x wall bracket

This product requires, but does not include, a motor and mirror ball, as well as appropriate fixtures

## **6. Snoezelen® Stimulations**

*Not applicable*

## **7. Best Use**

Use with a motor and mirror ball.

## **8. Compatible ROMPA® Products**

18524-5 – Motor

20549 – Spotlight & Colour Wheel

20550 – Spotlight without Colour Wheel

19007 – LED Spotlight

20878 – Wi Fi LED Spotlight

20546-7 – Mirror Ball

16322-4 – Coloured Mirror Ball

## **9. Starting Up**

- Safely attach the bracket to your wall.

## **10. Detailed Description**


Suitable for use where existing ceiling is too high or not strong enough. Drive unit not included. This bracket is 'L' shaped. On one side are two holes, and on the other are 5 smaller holes for the mirror ball motor.

## **11. Safety**

- For indoor, dry environments only. Keep away from moisture.
- Make sure the bracket is safely installed and can comfortably take the weight of the motor and mirror ball.

## 12. Technical Specification

Size: 30.5cmL  
Weight: 2kg  
Construction: Metal  
Thickness: 2.5mm



## 13. Installation

1. Unpack and keep the packaging in a safe place.
2. This product does not include fixtures – it is your responsibility to purchase appropriate fixtures. These should be appropriate to the construction of your wall and to the weight of the mirror ball and motor that will be used with it.
3. Safely and securely attach the bracket the wall using appropriate fixtures.

## **14. Care and Maintenance**


- Once this product is eventually exhausted, please dispose of it appropriately and responsibly.

## **15. Troubleshooting**

*Not applicable*

Further copies of these instructions can be downloaded at [www.rompa.com](http://www.rompa.com)

We hope you find our instructions invaluable. If you have any suggestions for improving them further your comments will be greatly received – please contact us at [producthelp@rompa.com](mailto:producthelp@rompa.com)



## 1. Produit

Accroche murale

## 2. Code

14817

## 3. Couleur

Selon disponibilité

## 4. Brève Description

À utiliser lorsque le plafond est trop haut ou pas assez solide.

## 5. Contenu

- 1 x accroche murale  
Ce produit nécessite un moteur et une boule à facettes ainsi que le matériel de fixation non compris

## **6. Stimulations Snoezelen®**

*Ne s'applique pas*

## **7. Usage**

Utilisation avec un moteur et une boule à facettes.

## **8. Produits Compatibles de ROMPA®**

18524-5 – Moteur

20549 – Discospot avec Roue Multicolore

20550 – Discospot sans Roue Multicolore

19007 – Discospot LED

20878 – Discospot LED Wi Fi

20546-7 – Boule à Facettes

16322-4 – Boule à Facettes Multicolores

## **9. Fonctionnement**

- Attachez votre accroche au mur de façon sûr.

## **10. Description**

À utiliser lorsque le plafond est trop haut ou pas assez solide. Le moteur n'est pas compris. Cette accroche est en forme d'un 'L'. Sur un côté il y a deux trous, et sur l'autre côté il y a 5 trous plus petits pour le moteur pour la boule à facettes.

## **11. Sécurité**

- Pour l'usage à l'intérieur, au sec seulement. Tenez à l'écart de l'eau et l'humidité.
- Vérifiez que l'accroche soit sûrement attachée et qu'elle puisse tenir le poids du moteur et de la boule à facettes sans risque.


## 12. Caractéristiques Techniques

Dimensions: 30.5cmL

Poids: 2kg

Construction: Métal

Épaisseur: 2.5mm



## 13. Installation

1. Déballez et gardez l'emballage dans un lieu sûr.
2. Ce produit ne comprend pas le matériel de fixation – vous avez la responsabilité d'acheter le matériel de fixation qui convient. Le matériel doit convenir à la construction et de votre mur et au poids de la boule à facettes et du moteur.
3. Il faut bien attacher l'accroche au mur en vous servant de matériel de fixation convenable.

## **14. Soin et Entretien**

- Dès que ce produit soit éventuellement épuisé, jetez-le de façon convenable et responsable.

## **15. En cas de problèmes**

*Ne s'applique pas*