

## **1. Product Name**

Fibre Optic UFO

## **2. Product Code**

16692

## **3. Colour**

Transparent base\*; white fibres

\* Base may be silver-coloured, subject to availability

## **4. Brief Description**

Captivating, fine fibre optics. Visually stimulating.

## **5. Contents**

- 1 x Fibre Optic UFO

## **6. Snoezelen® Stimulations**

- Sight

## **7. Best Use**

This product looks most effective in a darkened environment.

## **8. Compatible ROMPA® Products**

Please see [www.rompa.com](http://www.rompa.com) for more fibre optic products.

## **9. Starting Up**

- Insert 3 AAA batteries.
- Switch ON.

## **10. Detailed Description**

Captivating, fine fibre optics. Visually stimulating. Requires 3 AAA batteries.

## **11. Safety**

- Supervise the use of this product.

## **12. Technical Specification**

Size: base 8.5H x 8cm diameter; overall height 31cm  
Power: 3 x AAA batteries

### 13. Installation

1. Turn the lamp upside down. Using a cross-head screw driver open the battery compartment. Insert three AAA batteries, observing the polarity indicated.



2. Close the battery compartment and tighten the screw to secure in place.
3. If the fibre optics are not already in place in the top of the lamp, insert the solid end into the top of the lamp.
3. Make sure the ON / OFF switch is set to the ON position.

### 14. Care and Maintenance

- Do not immerse the unit in water.
- Change the batteries when operation becomes erratic.
- Remove the batteries when the product is not in use for prolonged periods.
- Do not use rechargeable batteries, and do not mix old and new batteries.


### 15. Troubleshooting

*Problem: the UFO will not illuminate*

- Replace the batteries as required. Make sure the ON / OFF switch is set to ON.

Further copies of these instructions can be downloaded at [www.rompa.com](http://www.rompa.com)

We hope you find our instructions invaluable. If you have any suggestions for improving them further your comments will be greatly received – please contact us at [producthelp@rompa.com](mailto:producthelp@rompa.com)



### **1. Nome do Produto**

Ovni de Fibras Ópticas

### **2. Código do Produto**

16692

### **3. Cor**

Base transparente; fibras brancas

### **4. Descrição Abreviada**

Fibras ópticas finas e cativantes. Visualmente estimulante.

### **5. Conteúdo**

1 x Ovni de Fibras Ópticas

### **6. Estimulação Snoezelen**

Visual

## **7. Melhor Utilização**

Este produto parece mais eficaz em ambientes escuros.

## **8. Compatibilidade com Produtos ROMPA**

Visite [www.rompa.com](http://www.rompa.com) para mais produtos com fibras ópticas.

## **9. Início**

- Introduza 3 pilhas AAA.
- Ligue

## **10. Descrição Detalhada**

Fibras ópticas finas e cativantes. Visualmente estimulantes. Necessita de 3 pilhas AAA.

## **11. Segurança**

- Supervisione sempre a utilização deste produto.

## **12. Especificações Técnicas**

Tamanho:	Base 8.5A x 8cm de diâmetro; altura total 31cm
Alimentação:	3 pilhas AAA

## **13. Instalação**

1. Vire a lâmpada ao contrário. Abra o compartimento das pilhas com uma chave de estrela. Introduza três pilhas AAA tendo em atenção a polaridade indicada.



- Feche o compartimento das pilhas e volte a apertar o parafuso.
2. Se as fibras ópticas ainda não estiverem colocadas no topo da lâmpada, introduza o canhão no topo da lâmpada.
  3. Verifique se o botão ON/OFF está na posição ON.

## **14. Cuidado e Manutenção**

- Não submerja em água.
- Substitua as pilhas quando o funcionamento ficar errático.
- Remova as pilhas quando o produto não for utilizado por longos períodos de tempo.
- Não utilize pilhas recarregáveis.

## **15. Resolução de Problemas**

*Problema: o ovni de fibras ópticas não se ilumina*

- Substitua as pilhas. Verifique se o botão ON/OFF está na posição ON.