



1. Product Name

Double Panel Porter

2. Product Code

18522

3. Colour

As shown

4. Brief Description

All the flexibility of the single porter, with even more advantages! Two panels can be used at one time and placed anywhere in a room.

5. Contents

- 1 x Porter
- 4 x fixing straps (2 black oblongs, 2 white oblongs, each with 2 pre-drilled holes)
- 8 screws

Please note: this product does not include a ROMPA® Panel. Panels must be purchased separately – see ROMPA® catalogue/website for further information.

6. Snoezelen® Stimulations

Not applicable

7. Best Use

Use to transport two ROMPA® Panels from room to room.

8. Compatible ROMPA® Products

This porter can be used with a range of ROMPA® Panels:

20566	Infinity and Beyond Panel
19603	Catherine Wheel Panel
20942	Sound to Light Wall Panel
19209	Colour Match Panel
20132	Snow Panel
18544	Fireworks Panel
18540	Mirrored Linelite Panel
18537	Interactive Fountain Panel
18539	Mirrored Fibre Optic Light Panel
19214	Colour Changing Panel

9. Starting Up

- No assembly is required for the Porter itself. Both the Single and Double Panel Porters arrive fully assembled.
- Make sure that your Panels are secured to the Porter before use.
- Use the castors to move the Porter as required, remembering to secure the brakes once the Porter is in the desired location, and before use.

10. Detailed Description

All the flexibility of a single porter, with even more advantages! Two panels can be used at one time and placed anywhere in a room. Excellent for use between two beds or chairs.

11. Safety

- Always supervise the use of this product.
- Use indoors in a dry environment.
- Before use, engage the brakes on the castors.
- Because of its weight, and water content, the Bubble Wall 18523 is not especially suited to a Porter – this Panel should be wall mounted.

12. Technical Specification

Size: 123.5H x 88.5w x 60.5cmD

13. Installation

1. Choose a suitable location for the Porter, making sure that the power cable will not be tripped over, pulled or come into contact with hot surfaces.
2. Insert the first panel into the side of the Porter where the L-shaped brackets are. Butt the bottom edge up to the wooden bar on the bottom of the Porter. Secure the panel to the porter by passing two screws through the two holes in the L-shaped bracket and into the back of the Panel. Plug the panel into the mains sockets on the bottom of the Porter.
3. Turn the Porter round and plug in the second panel into the mains sockets on the bottom of the Porter. Insert the second panel into the Porter. Again, butt this panel up to the wooden bar on the bottom of the Porter.
4. Both Panels should be joined with two connecting strips. Two white strips and two black strips are included as we offer a colour choice on our panels. Only two will be required at once to connect the panels. Using the screws provided (or the screws already in the top of the panels) pass a screw through each hole and into the panels.
5. The lead and plug from the multiple socket pass through the large hole on the side of the Porter and can be plugged into the mains supply (wall plug socket).
6. **Please note:** It is not recommended that any other products be connected to the Porter without seeking advice from a suitably qualified electrician.

14. Care and Maintenance

To clean the Porters use a mild household furniture polish and a duster, or wipe down using a damp cloth.

15. Troubleshooting

Not applicable.

Further copies of these instructions can be downloaded at www.rompa.com

We hope you find our instructions invaluable. If you have any suggestions for improving them further your comments will be greatly received – please contact us at

producthelp@rompa.com