



1. Product Name

Giant Oval Beanbag

2. Product Code

18694

3. Colour

Typically as shown.

4. Brief Description

A long tactile bean bag which can be used for sitting or lying.

5. Contents

• 1 x giant oval beanbag

6. Snoezelen® Stimulations

• Tactile

7. Best Use

Use as seating for children or adults.

8. Compatible ROMPA® Products

Many multisensory items can be used as passive or interactively whilst the client/s are sitting on the giant oval beanbag.

If you wish to increase sensory stimulation for your client/s, please refer to our catalogue or website www.rompa.com for a great selection of items that provide a huge variety of olfactory, tactile and visual input.

9. Starting Up

- Unpack item
- Decide where it is to be placed, considering potential risks and hazards in the surrounding space.
- Place on an even floor.
- Decide how the beanbag will be used, positioned to support the user.
- Help user transfer safely into an appropriate position for use (if appropriate).
- Ensure client is supervised using this product at all times.

10. Detailed Description

This giant oval beanbag is suitable for children or adults. It can accommodate one adult or several children (depending on their size). It comprises of two different fabrics which contrast with texture for tactile discrimination whilst providing visual stimulation with patterned and plain decoration. Can be used as a seating item just for relaxation or an area to sit whilst engaging in other activities.

11. Safety

- For indoor use only.
- For daytime use it is not intended to be slept upon.
- For 3 years and over.
- The beanbag should not be mouthed.
- Remove all packaging before use and store or dispose of this appropriately.
- Keep and use away from sources of heat e.g. fire, radiators etc



Please read all the Safety information below before each use

Remove all packaging and either store this in a safe place out of reach of clients or dispose of this responsibly. Plastic bags and wrapping can be hazardous to children and vulnerable people.

This product contains a foam or bead filling. The beads in the bead filling are small parts and should always remain out of reach. Do not attempt to access the interior part of this product. Never allow children or vulnerable people to access the interior part of this product.

Should any seams or the zip become damaged, contact ROMPA® immediately to arrange repair or replacement. Should the product require re-filling, contact ROMPA® immediately to discuss this.

Keep away from sources of heat and fire.

ALWAYS SUPERVISE THE USE OF THIS PRODUCT

12. <u>Technical Specification</u>

Filling: conforms to BS 5852/2 (fire-resistant)

polystyrene bead

Fabric: conforms to BS 5852pt1 (fire-resistant)

fur and poly/cotton

13. Installation

Unpack the product and dispose carefully of packaging materials.

Use the beanbag according to client need. Decide if they need to use lying or in a sitting position and if they need assistance transferring to use the item.

Please ensure that when positioning the beanbag in a space that a risk assessment of the surrounding space has been carried out to ensure the safety of the user and other people. Ensure that walkways and doors are not obstructed and that the item is not positioned near to sharp edges such as furniture corners etc to minimize potential risk if client/s move around.

14. Care and Maintenance

- Keep away from sharp and pointed objects.
- The cushion is intended to be sat on not jumped on.
- If the cushion is too firm for the user, you may wish to remove a small amount of the filling (keep this in a safe place for use at a future date).
- Regularly check the Giant Oval Beanbag for wear and tear. Discontinue use till repaired or replaced.
- The outer may be unzipped and removed for cleaning.
- Wash with care. This product can be machine-washed using a hand wash setting at 30°C. If your washing machine does not have such a setting, wash by hand.



Do not use bleach.



Do not iron.



Do not dry clean.



- The outer may be air-dried or tumble-dried at a low setting.
- Brush the fur after drying to restore the pile.
- Make sure the outer is thoroughly dry before use.

FABRIC MAINTENANCE

If you look after your soft cushioning it should give you many years of service.

But please observe the following:-

- 1. Fabric may wear, tear or "rub off" if subjected to sharp objects or continual rubbing by hard objects. Avoid shoes, buckles or sharp/hard objects.
- 2. Organise a regular cleaning schedule.
 - Wipe off accidental marks/liquids using a mild detergent and a damp cloth, avoiding excessive amounts of water. Do not use cleaners with abrasives in them or solvent-based cleaners such as trichloroethane or carbon tetrachloride. Liquid detergents used to wash cups/plates etc. are ideal. Do not steam clean.
- 3. From time to time lift beanbags to clean all surfaces and the floor underneath.

15. Troubleshooting

Not applicable

Further copies of these instructions can be downloaded at www.rompa.com

We hope you find our instructions invaluable. If you have any suggestions for improving them further your comments will be greatly received – please contact us at producthelp@rompa.com



POUF OVALE 18694





CONTENU

1 x Pouf Ovale

SOIN ET ENTRETIEN



On peut défaire la fermeture éclair pour enlever l'extérieur pour le nettoyage. Lavez avec soin. On peut laver ce produit à machine (un réglage bas à 30°C. Si votre machine n'a pas un tel réglage, il faut laver l'extérieur à main.



Ne pas se servir de l'eau de Javel.



Ne pas repasser.



Ne pas nettoyer à sec.

On peut sécher l'extérieur à l'air ou à machine (un réglage bas). Brosser le faux pelage après le séchage. Vérifiez que l'extérieur est sec avant de l'utiliser de nouveau.

SPECIFICATION

Rembourrage: conforme à BS 5852/2 (anti-feu)

billes en polystyrène

Tissu: conforme à BS 5852pt1 (anti-feu)

faux pelage et polyester coton

SURETE

Déballez avant de l'usage.

Il faut toujours surveiller l'usage de ce produit.



PUFE OVAL GIGANTESCO 18694





CONTEÚDO

1 x Pufe Oval Gigantesco

CUIDADO E MANUTENÇÃO



O exterior pode ser desapertado e removido para limpeza.

Lave com cuidado. Este produto pode ser lavado na máquina num programa de lavagem manual a 30°. Se a sua máquina não possuir um programa assim, lave à mão.



Não utilize lixívia.



Não passe a ferro.



Não lave a seco.

O exterior pode secar ao natural ou na máquina de secar a uma temperatura baixa. Escove o pelo depois de secar para restaurar a forma. Verifique se o exterior está devidamente seco antes de utilizar.

ESPECIFICAÇÕES

Enchimento: Conforme BS 5852/2 (retardante de fogo)

Enchimento de poliestireno

Tecido: Conforme BS 5852pt1 (retardante de fogo)

Pelo e poliéster/algodão

SEGURANÇA

Remova todo o material de embalagem antes de utilizar.

Supervisione sempre a utilização deste produto.