



BOING BALL - 19355

CONTENTS


- 1 x Boing Ball

USE

Pull out battery seal




Boing changes colour with a simple squeeze of your hand.



BATTERY CHANGE

- Pull off rubber mantle
- Unscrew the 2 halves
- Remove lid (2 screws)
- Insert batteries observing the polarity indicated. Only use the batteries specified (3 x 1.5V/AAA). Remove empty batteries from the product. Non-rechargeable batteries must not be recharged! Do not use different types of batteries, and do not mix new and used batteries. Always dispose of batteries safely.



GENERAL CARE

Don't drop the Boing ball from large heights or throw it against hard surfaces. It is not designed to bounce, and the electrics might get damaged.

If the rubber skin is dirty, it can be removed from the ball and gently washed with soap and water. To restore its original silky feel, dry it completely and treat with regular talcum powder before putting it back in place.

Please retain this information for future reference.

SPECIFICATION

Material: Rubber

Size: 7cm diameter

SAFETY

Always supervise the use of this product.

For 6 years and over.

Conforms to EN71 safety standards.