



1. Product Name

Tactile Squares by ROMPA®

2. Product Code

- 21791 Strands, Sounds & Spring 20807 – Harlequin 21792 – Colour Springy Spider (small) 20809 – Metallic 20810 – Fuzzy 21793 – Springy Trio 21794 – Balls Abacus 20813 – Magic Rods 20820 – Natural Springy Spider (small) 20821 – Fabric Fun
- 20824 Natural Springy Spider (large) 20825 – Linelite 21795 – Springy Jungle 21796 – Colour Springy Spider (large) 20829 – Bells Abacus 21798 – Spin, Ring, Boing 20831 – Bells 21797 – UV Carpet

20822 – Spiky Balls

20823 – Brushes

3. <u>Colour</u>

Natural wood finish base

4. Brief Description

Lovely textured resources that can be used on your lap/table top or quickly and easily slotted into one of three wall-mounted frames.

5. Contents

• 1 x Tactile Square

6. <u>Snoezelen® Stimulations</u>

- Sight
- Touch

7. Best Use

Use with one of our wall-mounted frames and regularly swap the Squares around.

8. Compatible ROMPA® Products

20833 – Standard Frame 20834 – Cloud Frame 20835 – Deluxe Frame (Custom-made design)

9. Starting Up

Use the Tactile Square on your lap, on a table top or use in a Frame that has been secured to a wall using appropriate fixtures (to be purchased separately).

10. Detailed Description

Lovely textured resources that can be used on your lap/table top or quickly and easily slotted into one of three wall-mounted frames. All the same size, these can be quickly interchanged in the frames to instantly update a sensory wall. Many also feature sounds and colours. Practical - most can be used any way up. An extensive range from the very simple to multi-coloured, moving designs. To be used with care, under supervision.

11. <u>Safety</u>

Always supervise the use of this product.

• Handle with care.

12. <u>Technical Specification</u>

Size: 29.6 x 29.6cm Weight: 1.5 – 2kg

13. Installation

Either:

- 1. Use the Tactile Square on your lap or on a table top. Or:
- 2. Use in a Frame that has been secured to a wall using appropriate fixtures. The Squares slot into the metal square-shaped supports on the frames, as shown below.



14. Care and Maintenance

1. Wipe clean with a soft and very slightly dampened cloth. Do not use bleach or abrasive cleaning products.

15. Troubleshooting

Not applicable

Further copies of these instructions can be downloaded at www.rompa.com

We hope you find our instructions invaluable. If you have any suggestions for improving them further your comments will be greatly received – please contact us at producthelp@rompa.com

TACTILE SQUARES 20806-20832, August 2015 Copyright ROMPA®Ltd