



Panoramic Rotator

1) Attach the lens adaptor collar onto the end of the projection lens



2) Place the panoramic rotator on the lens adaptor collar and fix into place by tightening the screws



3) Plug the wire from the panoramic rotator into the front of the projector

