



## 1. Product Name

Multi-Purpose Television

## 2. Product Code

22794

## 3. Colour

The plywood frame has a dark wood finish

## 4. Brief Description

With all the definition, reliability and quality of a modern TV with the reassuring and nostalgic appearance of early models.

## 5. Contents

- 1 x Multi-Purpose Television with integral DVD player

## 6. Snoezelen® Stimulations

- Sight

## 7. Best Use

Install indoors. The Multi-Purpose Television is especially effective when used with other items from the Multi-Purpose Reminiscence Furniture range (see below). This product is not intended to be sat upon.

## 8. Compatible ROMPA® Products

ROMPA® offers an extensive range of sensory and reminiscence products. Please visit our websites [www.rompa.com](http://www.rompa.com) and [www.olderadults.co.uk](http://www.olderadults.co.uk) for more information.

### Multi-Purpose Reminiscence Furniture

22793 Grandfather Glow Clock

22791 Infinity Table

22789 Rocking Chair

20525 Nostalgia Music Centre

22795 Illuminated Book Case

22792 Faux Flame 'Fireplace'

22790 Fibre Optic Table



### Wi Fi compatibility

This unit has HDMI and VGA ports at the back for use with our Sensory Magic® system:

20848 Wall-mounted Sensory Magic®

21098 Portable Sensory Magic®

### DVDs

ROMPA® offers a large range of DVDs, including DVDs for relaxation as well as DVDs with reminiscence-based content. Please visit [www.rompa.com](http://www.rompa.com) and [www.winslowresources.com](http://www.winslowresources.com) for more information:

20484 Forest Seasons

20515 Rainforest Creeks

20482 Nature's Alarm Clock

20088 Kaleidovisions

20513 Water Melodies

20483 Butterflies and Flowers

20087 Dreamscapes

20089 Starlight

## 9. Starting Up

- Choose a suitable location near to a double wall socket
- Plug both plugs in (from the television and DVD player)

## 10. Detailed Description

With all the definition, reliability and quality of a modern TV with the reassuring and nostalgic appearance of early models. The old-style exterior deceptively houses an up-to-date television, allowing viewing of favourite programmes. Also includes a DVD Player as well as HTMI and VGA ports at the back for use as a projector for our Sensory Magic® system (see page 9). With an integral shelf for storage. Mains-powered.

Weight: 25kg

Size: 74L x 40W x 77cmH

The 'controls' on the front of the television are for decorative purposes only – these have no operational function.

## 11. Safety

- **Always supervise the use of this product**
- This product weighs approximately 25kg – two people should take delivery of this product and install it.
- This product is decorative and not intended to be sat or stood upon.
- For indoor use only, in a dry and clean environment.
- Allow adequate ventilation around the unit.

## 12. Technical Specification

Size: 74L x 40W x 77cmH

Weight: approximately 25kg

Please refer to the separate manuals supplied with the product for the integral television and the DVD player. Models of these may vary according to availability.

## **13. Installation**

1. Choose an appropriate location for the Multi-Purpose Television, bearing in mind that:
  - It needs to be plugged in (two plugs)
  - The product weighs approximately 25kg – please choose a suitably flat and stable floor
  - This product is free-standing.
  - You may wish to access the rear of the unit to access the ports and DVD player.
2. Plug the products in. The appropriate connections inside this unit have already been made so no assembly/connecting is required.
3. Please refer to the separate manuals supplied with the product for the integral television and the DVD player.

## **14. Care and Maintenance**

1. Periodically dust the product with a soft and dry cloth.
2. To remove any dirt or more persistent marks, use a soft and very slightly dampened lint-free cloth. Avoid the use of any cleaning products, especially abrasive cleaning products, bleach or anti-bacterial sprays as these can damage varnished/lacquered surfaces.
3. Treat this television as you would any other. For example, use coasters or mats when placing objects on the top that could potentially scratch or damage the surface.
4. If using the integral shelf, place only appropriate objects on this – do not overload the shelf.

## **15. Troubleshooting**

*Not applicable*

Further copies of these instructions can be downloaded at [www.rompa.com](http://www.rompa.com)

We hope you find our instructions invaluable. If you have any suggestions for improving them further your comments will be greatly received – please contact us at [producthelp@rompa.com](mailto:producthelp@rompa.com)