



1. Product Name

Illuminated Book Case

2. Product Code

22795

3. Colour

The plywood frame has a dark wood finish whilst the lights automatically cycle through various colours.

4. Brief Description

Perfectly displays treasured trinkets, prized possessions and beloved belongings. Spacious shelving allows books, nostalgic items, reminiscence resources, activities and comforting objects to be stored in a tidy and accessible way.

5. Contents

- 1 x Illuminated Book Case (*contents shown are for illustration purposes only*)

6. Snoezelen® Stimulations

- Sight

7. Best Use

Install indoors and either enjoy passively or with one of ROMPA®'s Wi Fi controllers for wireless interactivity. The Illuminated Book Case is especially effective when used with other items from the Multi-Purpose Reminiscence Furniture range (see below). This product is not intended to be sat or stood upon.

8. Compatible ROMPA® Products

ROMPA® offers an extensive range of sensory and reminiscence products. Please visit our websites www.rompa.com and www.olderadults.co.uk for more information.

Multi-Purpose Reminiscence Furniture

22793 Grandfather Glow Clock

22794 Multi-Purpose Television

22791 Infinity Table

22792 Faux Flame 'Fireplace'

22789 Rocking Chair

22790 Fibre Optic Table

20525 Nostalgia Music Centre



Wi Fi compatibility

This unit is ROMPA® Wi Fi compatible, and therefore will respond wirelessly to the following remote controllers:

- 18870, 20402 - Talking Cubes
- 19847 – Deluxe 8 Colour Wirefree Controller
- 21006 – 8 Colour Wirefree Controller
- 19939 – Wi Fi Interactive Mat Switch Set
- 21917 – Wi Fi Microphone by ROMPA®
- 21918 – Wi Fi Override Transmitter
- 20848, 21098 – Sensory Magic®

9. Starting Up

- Choose a suitable location near to a wall socket.
- Plug in.

10. Detailed Description

Perfectly displays treasured trinkets, prized possessions and beloved belongings. Spacious shelving allows books, nostalgic items, reminiscence resources, activities and comforting objects to be stored in a tidy and accessible way. No ordinary book case, this sturdy ROMPA® unit has built-in LEDs to better show items placed on it and to provide subtle and colour-changing lighting.

Weight: 36kg

Size: 95W x 28D x 129cmH

The LED light strip used in the Illuminated Book Case turns on automatically once plugged into the mains, automatically cycling through a rainbow of colours. The light strip is compatible with ROMPA® Wi Fi controllers and will change colour when a Wi Fi controller is in operation. When controlled in this way, the Wi Fi LED strip will change to the selected colour for one minute, before returning to automatic mode.

11. Safety

- **Always supervise the use of this product**
- This product weighs approximately 36kg – two people should take delivery of this product and install it.
- This product is decorative and not intended to be sat or stood upon. This product is unlikely to withstand the weight of a person.
- For indoor use only, in a dry and clean environment.

12. Technical Specification

Size: 95W x 28D x 129cmH
Power: Consumption 24 watts
Input: 100-240v AC 50/60Hz 0.7A
Output: 12v DC 60W ma
Weight: approximately 36kg

13. Installation

1. Choose an appropriate location for the Illuminated Book Case, bearing in mind that:
 - It needs to be plugged in (one plug)
 - The illuminated effect will be strongest in darker environments than in bright day light
 - The product weighs approximately 36kg – please choose a suitably flat and stable floor
 - This product is free-standing.
2. Plug the product in. There is no ON/OFF switch – the product will light up automatically once plugged in. The light will change colour in sequence unless a ROMPA® wireless controller is used to choose a particular colour of light. The automatic colour light sequence will resume one minute after the ROMPA® wireless controller has been activated.

14. Care and Maintenance

1. Periodically dust the product with a soft and dry cloth.
2. To remove any dirt or more persistent marks, use a soft and very slightly dampened cloth. Avoid the use of any cleaning products, especially abrasive cleaning products, bleach or anti-bacterial sprays as these can damage varnished/lacquered surfaces.
3. Treat this book case as you would any other coffee table. For example, use coasters or mats when placing objects on the shelves that could potentially scratch or damage the surface.

15. Troubleshooting

Not applicable

Further copies of these instructions can be downloaded at www.rompa.com

We hope you find our instructions invaluable. If you have any suggestions for improving them further your comments will be greatly received – please contact us at

producthelp@rompa.com