



1. Product Name

Gliding Chair with Footrest

2. Product Code

22966

3. Colour

As shown.

4. Brief Description

Soothing and stylish, this 2-piece set can aid relaxation.

5. Contents

- 1 x Chair
- 1 x Footrest

6. Snoezelen® Stimulations

- Vestibular

7. Best Use

Use indoors in an appropriate area.

8. Compatible ROMPA® Products

ROMPA® have a range of items that enable individuals to benefit from a range of different movements including different rocking motions, spinning, bouncing etc. Please look at our full range on www.rompa.com.

9. Starting Up

- Assess the area where you are considering putting the equipment for safety, ensuring that the movement will not obstruct walkways, doorways, drawers, cupboards or thoroughfares.
- Put the equipment on a level surface.
- Follow installation instructions.

10. Detailed Description

Soothing and stylish, this 2-piece set can aid relaxation. For ultimate comfort, the footrest rocks in sync with the chair. With a beech wood frame, thick cushions and padded arms.

11. Safety

- Do not sit on the footrest. This is for resting feet on and not designed/manufactured to take the weight of an individual.
- If the item needs to be moved, ensure that this is done without being loaded with products or with a person still seated.
- The Gliding Chair is not intended to be chewed, pulled on, pierced or misused – always supervise the use of these products.
- Do not put the chair and/or footstool close to a heat source such as a fire, radiator etc.
- This product contains bolts and other small parts that may present a choking hazard for children and vulnerable adults. Please ensure that all small parts are kept away from those at risk and that packaging is disposed of appropriately.



12. Technical Specification

Materials: the paint and varnish are non-toxic


Weight: 22kg

Size: 110 x 60 x 100cm

13. Installation




2




⚠ WARNING: Do not over tighten bolts


3




4



5



6



14. Care and Maintenance

If you look after your Gliding Chair with Footrest it should give you many years of service.

Please observe the following:

- The Fabric may damage if subjected to sharp objects or continual rubbing by hard objects.
- Avoid shoes, buckles or sharp/hard objects coming into contact with the Gliding Chair and footstool
- Organise a regular cleaning schedule.
- Wipe off accidental marks/liquids using a mild detergent and a damp cloth, avoiding excessive amounts of water. Do not use corrosive cleaners or bleach.
- If minor surface damage occurs, limited amounts of beeswax may help to maintain the appearance of the product.
- Keep the equipment away from sunlight or extreme atmospheric fluctuations which can affect the product.

15. Troubleshooting

Not applicable

Further copies of these instructions can be downloaded at www.rompa.com

We hope you find our instructions invaluable. If you have any suggestions for improving them further your comments will be greatly received – please contact us at

producthelp@rompa.com