



## 1. Product Name

Slide and Hide

## 2. Product Code

23173

## 3. Colour

Natural maple wood colour

## 4. Brief Description

An all-in-one indoor unit to encourage a range of movements and motor skills for children under 3 years.

## 5. Contents


2 boxes containing components shown on next page  
A screw driver will be required (not included)  
Two adults are required to assemble the Slide and Hide

## 6. Snoezelen® Stimulations


*Not applicable*

## 7. Best Use


Use on a flat and stable surface with appropriate floor mats.



A  
PN: 7130101  
QTY 1



B  
PN: 7130201  
QTY 1



C  
PN: 7130301  
QTY 1

KIT  
(SOME EXTRA'S INCLUDED)




SUPERJOINER F1  
PN: FS6338SW4  
QTY 21




BOLT & SLEEVE F2  
M6 x 30  
PN: FBM630SL  
QTY 2



ALLEN KEY  
PN: AMSW4  
QTY 1




D  
PN: 7130401  
QTY 1



F  
PN: 7130601  
QTY 1



H  
PN: 7130801  
QTY 3



E  
PN: 7130501  
QTY 1



G  
PN: 7130701  
QTY 2



J  
PN: 713HW01  
QTY 1

PACK 1 OF 2

PACK 2 OF 2

## **8. Compatible ROMPA® Products**

Visit [www.rompa.com](http://www.rompa.com) to see our full range

## **9. Starting Up**

- Read all the instructions then assemble according to the diagrams provided.

## **10. Detailed Description**

An all-in-one indoor unit to encourage a range of movements and motor skills for children under 3 years. Useful for climbing, crawling, balancing and sliding, as well as turn-taking and co-operative play. MDF with a maple finish. Flat pack – simple assembly required.

## **11. Safety**

- **Always supervise the use of this product.**
- Always use with safety mats.
- Do not allow children over 3 (or above the weight of a typical 3 year old) to use this product.
- For indoor use only.

## **12. Technical Specification**

Size: 85.5L x 139W x 59cmH

Weight: 39kg

## **13. Installation**



1. Read all the instructions before beginning assembly.
2. Carefully follow all the steps illustrated below in the diagrams.
3. Care must be taken not to overtighten the fasteners.



## **14. Care and Maintenance**


1. Clean the Slide and Hide using a slightly damp cloth. Stubborn marks may be removed with a mild detergent or non-abrasive cream cleaner.
2. Examine all fasteners periodically and re-tighten where necessary. Care must be taken not to overtighten the fasteners.

## **15. Troubleshooting**

*Not applicable*







Further copies of these instructions can be downloaded at [www.rompa.com](http://www.rompa.com)

We hope you find our instructions invaluable. If you have any suggestions for improving them further your comments will be greatly received – please contact us at [producthelp@rompa.com](mailto:producthelp@rompa.com)