



1. Product Name

Hip Hop Jumping Cushion

2. Product Code

19229

3. Colour

Colours may vary

4. Brief Description

Provides hours of healthy fun for children. Has a strong padding and has no frame or edges.

5. Contents

- 1 x cushion

6. Snoezelen® Stimulations

Not applicable

7. Best Use

Use on a flat, stable floor away from obstacles.

8. Compatible ROMPA® Products

This cushion could be used as part of a sensory circuit – see www.rompa.com for our full range of sensory integration and balance products.

9. Starting Up

- Unpack and place on a suitable surface. Make sure the non-slip side is against the floor.

10. Detailed Description

Provides hours of healthy fun for children. Has a strong padding and has no frame or edges. The special springs are completely integrated and create pressure when jumping, and a surface to relax on. Made from a very durable structural material. The bottom is made from non-slip mat material for safety. Maximum user weight 40kg.

Size: 116 x 76 x 25cm

11. Safety

- Always supervise the use of this product.
- Use on a flat, stable surface that can easily support the weight of this product and users up to 40kg in total i.e. a solid floor.
- Use away from obstacles. Allow plenty of space above and around the cushion.
- The cushion may be used by one or two people and will support a maximum combined weight of 40kg.
- Use with additional safety mats as necessary.
- Do not allow the zip to be undone and the interior to be accessed.

12. Technical Specification

Size: 116 x 76 x 25cm

This cushion is not fire-retardant

13. Installation

1. Unpack and place on a suitable indoor surface (i.e. flat, solid, stable floor away from stairs etc).
2. Make sure the non-slip side is against the floor.

14. Care and Maintenance

1. Use and store indoors.
2. To clean, wipe with a soft, clean and slightly damp cloth. Avoid abrasive cleaning products so as not to scratch the fabric. Avoid excessive amounts of water.
3. The zip is for manufacturing purposes – the cover is not intended to be removed.
4. Avoid contact with sharp or pointed objects such as shoe buckles. Ideally remove shoes and use with stocking feet.
5. Keep away from fire, flame and extreme temperatures.
6. Store in the box it is supplied in when the Cushion is out of use to help keep it clean.

15. Troubleshooting

Not applicable

Further copies of these instructions can be downloaded at www.rompa.com

We hope you find our instructions invaluable. If you have any suggestions for improving them further your comments will be greatly received – please contact us at producthelp@rompa.com



1. Nome do Produto

Almofada para Saltos

2. Código do Produto

19229

3. Cor

As cores podem variar

4. Descrição Breve

A almofada para saltos proporciona horas de divertimento saudável para todas as crianças.

5. Conteúdo

- 1 x almofada

6. Estimulação Snoezelen®

não aplicável

7. Melhor Utilização

Coloque numa superfície plana, longe de obstáculos.

8. Compatibilidade com Produtos ROMPA®

Visita www.rompa.com

9. Começar

- Desempacote e coloque numa superfície plana, longe de obstáculos. O lado com a superfície anti deslizante deve estar virado para o chão.

10. Descrição Detalhada

A almofada para saltos proporciona horas de divertimento saudável para todas as crianças. Tem um acolchoamento forte e não tem armação ou pontos afiados. As molas especiais estão totalmente integradas, criam pressão quando se salta e uma superfície em que se pode relaxar. Fabricado em material estrutural de longa duração. O fundo é feito de material anti deslizante para maior segurança.

Tamanho: 116 x 76 x 25cm

11. Segurança

- Supervisione a utilização deste produto
- Utilize numa superfície plana e estável que consiga suportar o peso facilmente, ex.: chão sólido. Considere a localização cuidadosamente – deixe muito espaço por cima e à volta da almofada.
- A almofada destina-se até 2 pessoas ao mesmo tempo (max. 40 kg).
- Utilize com outras medidas de segurança se necessário, ex.: colchões.
- O fecho é para fins de fabrico – a cobertura não deve ser removida

12. Especificações Técnicas

Tamanho: 116 x 76 x 25cm

Este produto não é resistente ao fogo.

13. Instalação

1. Desempacote e coloque numa superfície plana, longe de obstáculos.
2. O lado com a superfície anti deslizante deve estar virado para o chão.

14. Cuidado e Manutenção

1. Para utilizar no interior.
2. Limpe com um pano macio, limpo e ligeiramente húmido. Evite produtos de limpeza abrasivos para riscar o tecido. Evite quantidades excessivas de água.
3. O fecho é para fins de fabrico – a cobertura não deve ser removida.
4. Evite o contacto com objetos afiados e pontiagudos tais como fivelas dos sapatos. O ideal é remover os sapatos.
5. Mantenha afastado do fogo, chamas e temperaturas extremas.
6. Guarde na caixa em que é fornecido quando não estiver a utilizar para ajudar a manter limpo.

15. Resolução de Problemas

não aplicável