

SPARKLING TUNNEL 19964



CONTENTS

- 1 x Sparkling Tunnel
- 1 x Light Source
- 1 x Switch

INSTALLATION

- Install the Sparkling Tunnel in an appropriate place on a flat, stable surface, bearing in mind the following:
 - The size of the Sparkling Tunnel: 90 x 90 x 90cm
 - The weight of the Sparkling Tunnel: 51kg
 - Access to a wall socket the light source needs to be plugged in and you may wish
 to wall mount this out of reach
 - Clear access into and out of the tunnel
 - The Tunnel will support the weight of children climbing on to it you may wish to consider Soft Play steps next to it
 - The length of the light source cable: approximately 2.7m

BEFORE USE

- 1. Choose a suitable location for the light source. Whilst it does not get hot, it should not be placed in an unsafe location (e.g. make sure no-one will walk into it/trip over it etc).
- 2. Connect the light source to the Sparkling Tunnel.
- 3. Plug in the light source and switch on at the wall.
- 4. Connect the switch to the jack socket (near to the tunnel at floor level) and press as required to activate the carpet on the inside of the tunnel.
- 5. Follow the instructions supplied with the Light Source should you wish to program your Light Source to display different colours to those that have already been pre-programmed.
- 6. Make sure users have removed their shoes.

SAFETY

Always supervise the use of this product.

CARE AND MAINTENANCE

Vinyl will crack, tear and "rub off" if subjected to sharp objects or continual rubbing by hard objects. Avoid shoes, buckles or sharp/hard objects.

- 1. Organise a regular cleaning schedule.
- 2. Wipe accidental marks/liquids off the vinyl using a mild detergent and a damp cloth, avoiding excessive amounts of water. Do not use cleaners with abrasives in them or SPARKLING TUNNEL 19964, KH 3.10

solvent-based cleaners such as trichloroethane or carbon tetrachloride. Liquid detergents used to wash cups/plates etc. are ideal or Dirt Lift 14800. Do not steam clean.

3. Do not pull on the light source cables.

- 4. Vacuum the carpet from time to time and clean as required using a minimal amount of a very mild carpet-cleaning product.
- 5. The floor mat is held in place by Velcro and it is secured to the bottom of the Tunnel. Therefore the Tunnel would need to be lifted up to remove the mat.

SPECIFICATION

Light source:

Size:

20.5L x 11.5W x 9cmH

Weight:

922g

Input:

100-240v AC 50/60Hz 0.25A

Output: Meets requirements of BS EN 9001-2000

12v DC 1.25A 15W max

Tunnel:

Phthalate-free vinvl

Carpet: Conforms to Flammability requirements BS4790 Low Radius of effects of ignition Carpet is an 80% wool, 20% nylon mix with a Hessian backing and is phthalate-free.